VMS ONVIF COMPATIBILITY CHART



COMPATIBLE WITH:













RELEASE DATE: 07/04/2024

REVISION FREQUENCY: 3 MONTHS

END-TO-END AI VIDEO SOLUTIONS



CRÉATEURS DE SOLUTIONS VIDÉO D'IA



























CIVIGILON a Motorola Solutions Company	FUNCTIONS	V01	Voc	V01	V21	VAO	VAO	Vaa
DEVICE SEARCH	AUTO SEARCH	V21	V26	V31	FISHEYE	V40	V43	V44
	H264 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
DDEVIEW	H265 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H265 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	BRIGHTNESS	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
IMAGE	CONTRAST	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
IMAGE	SATURATION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SHARPNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	CODEC H264 AND H265 SWITCH	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	RESOLUTION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
CODEC SETTINGS	FRAME RATE	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	STREAM RATE DATA	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	IMAGE QUALITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
AUDIO	NVR PLAY IPC AUDIO	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE IPC'S MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE / DISABLE MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTION DETECTION	MOTION DETECTION ALARM	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	MOTION REGIONS SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	SENSITIVITY	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	ENABLE / DISABLE TIME, CHANNEL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
OSD	POSITION SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
<u> </u>	MODIFY CHANNEL NAME	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR SYNC OSD NAME TO IPC	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	ZOOM	FAIL	FAIL	FAIL	FAIL	PASS	PASS	PASS
MOTORIZED	FOCUS	FAIL	FAIL	FAIL	FAIL	PASS	PASS	PASS
DHC P	PLUG AND PLAY	PASS	PASS	PASS	PASS	PASS	PASS	PASS

n^{x}	FUNCTIONS	V21	Vac	V21	V21	V40	V42	VAA
DEVICE SEARCH	AUTO SEARCH	V21	V26	V31	FISHEYE	V40	V43	V44
	H264 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H265 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	BRIGHTNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	CONTRAST	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	SATURATION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SHARPNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	CODEC H264 AND H265 SWITCH	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	RESOLUTION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
CODEC SETTINGS	FRAME RATE	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	STREAM RATE DATA	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	IMAGE QUALITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
AUDIO	NVR PLAY IPC AUDIO	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE IPC'S MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE / DISABLE MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTION DETECTION	MOTION DETECTION ALARM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	MOTION REGIONS SETTING	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SENSITIVITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	ENABLE / DISABLE TIME, CHANNEL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
OSD	POSITION SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	MODIFY CHANNEL NAME	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR SYNC OSD NAME TO IPC	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	ZOOM	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTOKIZED	FOCUS	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
DHC P	PLUG AND PLAY	PASS	PASS	PASS	PASS	PASS	PASS	PASS

DW	FUNCTIONS	V21	Vac	V31	V21	V40	V40	V44
DEVICE SEARCH	AUTO SEARCH	VZI	V26	VOI	FISHEYE	V40	V43	V44
	H264 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H265 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	BRIGHTNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	CONTRAST	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	SATURATION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SHARPNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	CODEC H264 AND H265 SWITCH	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	RESOLUTION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
CODEC SETTINGS	FRAME RATE	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	STREAM RATE DATA	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	IMAGE QUALITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
AUDIO	NVR PLAY IPC AUDIO	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE IPC'S MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE / DISABLE MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTION DETECTION	MOTION DETECTION ALARM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	MOTION REGIONS SETTING	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SENSITIVITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	ENABLE / DISABLE TIME, CHANNEL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
OSD	POSITION SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
USD	MODIFY CHANNEL NAME	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR SYNC OSD NAME TO IPC	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	ZOOM	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	FOCUS	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
DHC P	PLUG AND PLAY	PASS	PASS	PASS	PASS	PASS	PASS	PASS

WAVE WY	FUNCTIONS	V21	Vac	V21	V21	V40	V42	V44
DEVICE SEARCH	AUTO SEARCH	V21	V26	V31	FISHEYE	V40	V43	V44
	H264 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H265 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	BRIGHTNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	CONTRAST	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	SATURATION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SHARPNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	CODEC H264 AND H265 SWITCH	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	RESOLUTION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
CODEC SETTINGS	FRAME RATE	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	STREAM RATE DATA	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	IMAGE QUALITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
AUDIO	NVR PLAY IPC AUDIO	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE IPC'S MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE / DISABLE MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTION DETECTION	MOTION DETECTION ALARM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	MOTION REGIONS SETTING	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SENSITIVITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	ENABLE / DISABLE TIME, CHANNEL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
OSD	POSITION SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	MODIFY CHANNEL NAME	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR SYNC OSD NAME TO IPC	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	ZOOM	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	FOCUS	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
DHC P	PLUG AND PLAY	PASS	PASS	PASS	PASS	PASS	PASS	PASS

milestone	FUNCTIONS	V21	Voc	V-91	V21	V40	V49	VAA
DEVICE SEARCH	AUTO SEARCH	V21	V26	V31	FISHEYE	V40	V43	V44
	H264 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H265 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	BRIGHTNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	CONTRAST	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	SATURATION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SHARPNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	CODEC H264 AND H265 SWITCH	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	RESOLUTION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
CODEC SETTINGS	FRAME RATE	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	STREAM RATE DATA	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	IMAGE QUALITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
AUDIO	NVR PLAY IPC AUDIO	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE IPC'S MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE / DISABLE MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTION DETECTION	MOTION DETECTION ALARM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	MOTION REGIONS SETTING	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SENSITIVITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	ENABLE / DISABLE TIME, CHANNEL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
OSD	POSITION SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
USD TO THE PERSON OF THE PERSO	MODIFY CHANNEL NAME	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR SYNC OSD NAME TO IPC	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	ZOOM	FAIL	FAIL	FAIL	FAIL	PASS	PASS	PASS
MOTORIZED	FOCUS	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
DHC P	PLUG AND PLAY	PASS	PASS	PASS	PASS	PASS	PASS	PASS

Genetec [™]	FUNCTIONS	V21	V26	V31	V21	V40	V43	V44
DEVICE SEARCH	AUTO SEARCH	VZI	VZO	VOI	FISHEYE	V4U	V43	V44
	H264 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 MAIN STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
PREVIEW	H265 SUB STREAM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H264 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	H265 NO PAUSE/DELAY ISSUES	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	BRIGHTNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	CONTRAST	PASS	PASS	PASS	PASS	PASS	PASS	PASS
IMAGE	SATURATION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SHARPNESS	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	CODEC H264 AND H265 SWITCH	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	RESOLUTION	PASS	PASS	PASS	PASS	PASS	PASS	PASS
CODEC SETTINGS	FRAME RATE	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	STREAM RATE DATA	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	IMAGE QUALITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
AUDIO	NVR PLAY IPC AUDIO	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE IPC'S MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR ENABLE / DISABLE MOTION DETECTION	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTION DETECTION	MOTION DETECTION ALARM	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	MOTION REGIONS SETTING	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	SENSITIVITY	PASS	PASS	PASS	PASS	PASS	PASS	PASS
	ENABLE / DISABLE TIME, CHANNEL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
OSD	POSITION SETTING	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	MODIFY CHANNEL NAME	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
	NVR SYNC OSD NAME TO IPC	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
MOTORIZED	ZOOM	FAIL	FAIL	FAIL	FAIL	FAIL	PASS	PASS
MOTORIZED	FOCUS	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL	FAIL
DHC P	PLUG AND PLAY	PASS	PASS	PASS	PASS	PASS	PASS	PASS